



***Contactors, Capacitor Switching Contactors and Reversing Contactors Catalogue  
Number Explanation***

<b>100 – C</b>	<b>*</b>	<b>E *</b>	<b>*</b>
<b>100Q - C</b>	<b>*</b>	<b>E *</b>	<b>*</b>
<b>104 – C</b>	<b>*</b>	<b>E *</b>	<b>*</b>
<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>

<b>Position</b>	<b>Catalogue No. Suffix</b>	<b>Options/Descriptions</b>
1	100 – C 100Q - C 104 - C	Base Catalogue Number of Contactors (3 pole and 4pole) Base Catalogue Number of Capacitor Switching Contactors (3pole) Base Catalogue Number of Reversing Contactors (3 pole)
2	09, 12, 16, 23, 30, 37, 43 16, 37	Contact size for 100-C... and 104-C... Contact size for 100Q-C...
3	EJ	Coil code (24VDC, electronically controlled coil)
4	00, 01, 10, 200, 300, 400 11, 20 02, 22	Contact Configuration of Contactor Contact Configuration of Capacitor Switching Contactor Contact Configuration of Reversing Contactor

***Safety Contactors and Safety Reversing Contactors Catalogue Number  
Explanation***

<b>100S – C</b>	<b>*</b>	<b>E *</b>	<b>*</b>	<b>*</b>	<b>C</b>
<b>104S – C</b>	<b>*</b>	<b>E *</b>	<b>*</b>	<b>*</b>	<b>C</b>
<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>

<b>Position</b>	<b>Catalogue No. Suffix</b>	<b>Options/Descriptions</b>
1	100S – C 104S - C	Base Catalogue Number of Safety Contactors (3 pole and 4pole) Base Catalogue Number of Safety Reversing Contactors (3 pole)
2	09, 12, 16, 23, 30, 37, 43	Contact size
3	EJ	Coil code (24VDC, electronically controlled coil)
4	02, 03, 04, 05, 11, 12, 13, 14, 21, 22, 23, 31, 32, 41, 204, 222, 302, 304, 311, 313, 322, 331' 402, 404, 411, 413, 414, 422, 431, 432  08, 010, 012, 210	Contact Configuration of Safety Contactor  Contact Configuration of Safety Reversing Contactor
5	No suffix letter  B	Standard Contact Construction of Auxiliary Contact Block  Bifurcated Contact Construction of Auxiliary Contact Block
6	C	Indicates that the safety contactor is provided with a latch clip which serves to prevent from taking apart the safety-auxiliary contact block by hand.