

# Equipment Supervisor Faceplate Help

## Commands



Toggle switch on state



Toggle switch off state



Toggle switch disabled



Radio button on state



Radio button off state



Disabled radio button in on state



Disabled radio button in off state

## Status Indicators



Status Active/True



Status Inactive/False